



กล่องอะโรมา (Aroma Steam Box)
ยี่ห้อ Steamtec
รหัส SB01

รายละเอียดสินค้า

กล่องอะโรมา Steamtec รหัส SB01
วัสดุสแตนเลส304 บรรจุน้ำได้สูงสุด 1.9ลิตรL
ขนาดกล่อง ก.3.5 x ย.28 x ส.20ซม
ออกแบบมาเพื่อใช้สำหรับเตาชาวนา Steamtec

Steamtec Aroma Steam Box

- กล่องสร้างไอน้ำและกระจายกลิ่นอโรมาสำหรับห้องชาวนา ผลิตจากสแตนเลส 304
- สามารถบรรจุน้ำได้สูงสุด 1.9 ลิตร โดยติดตั้งบริเวณระหว่างชุดฮีตเตอร์ของเตาชาวนา
- ความร้อนจากเตาจะทำให้ไอน้ำภายในกล่องเกิดไอน้ำ และช่วยกระจายกลิ่นหอมจากช่องอโรมาเข้าสู่ห้องชาวนา เพื่อเพิ่มความผ่อนคลายระหว่างการอบชาวนา

หลักการทำงาน

ตัวกล่องสแตนเลสจะทำหน้าที่เป็น ถังน้ำขนาด 1.9 ลิตร เมื่อวางอยู่ภายในบริเวณที่ได้รับความร้อนจากฮีตเตอร์ของเตาชาวนา

1. เติมน้ำลงในตัวถัง

- เติมน้ำสะอาดประมาณ 2 ลิตร
- ไม่ควรเติมจนล้น เพราะต้องมีพื้นที่สำหรับการเดือดและการเกิดไอน้ำ

2. เติมน้ำหอมหรือน้ำมันอโรมา

- สินค้ารุ่นนี้ มี ช่องสำหรับใส่สารอโรมาอยู่บริเวณด้านบน
- กลิ่นจะถูกปล่อยออกมาเมื่อความร้อนทำให้น้ำเกิดไอน้ำ

3. ความร้อนจากเตาชาวนาทำให้น้ำร้อน

- ตัวกล่องไม่ได้มีลักษณะเป็นเครื่องกำเนิดไอน้ำแยกต่างหาก แต่ใช้ความร้อนจากเตาชาวนา
- ภายในกล่องมีพื้นที่รับความร้อน และจากรูปจะเห็นชุดท่อ/ฮีตเตอร์อยู่โดยรอบ

4. ไอน้ำและกลิ่นหอมกระจายออกทางช่องด้านบน

- เมื่อมีความร้อนเพียงพอ น้ำจะค่อย ๆ ระเหย
- ไอน้ำจะพากลิ่นอโรมาออกสู่ห้องชาวนา ทำให้เกิดบรรยากาศแบบ Aromatherapy Sauna

ข้อควรระวัง ⚠

จะต้อง แยก “น้ำในกล่องอะโรมา” กับ “น้ำมันอโรมา” ออกจากกัน ไม่ควรเทน้ำมันหอมระเหยลงไปผสมกับน้ำในถังโดยตรง กล่องอะโรมารุ่นนี้มี ช่องสำหรับใส่อโรมา บริเวณด้านบน และการออกแบบมีวัตถุประสงค์เพื่อหลีกเลี่ยงการสัมผัสโดยตรงของน้ำมันกับส่วนให้ความร้อน



Aroma Steam Box

Brand: Steamtec

Code: SB01

Description:

Steamtec Aroma Box – SB01

Material: 304 Stainless Steel

Maximum Water Capacity: 1.9 L

Dimensions (W × L × H): 3.5 × 28 × 20 cm

Compatible with: Steamtec Sauna Heaters

Steamtec Aroma Steam Box

- A steam-generating and aroma-diffusing box designed for use in sauna rooms, made of 304 stainless steel.
- The box has a maximum water capacity of 1.9 liters and is installed between the heating elements of the sauna heater.
- Heat generated by the sauna heater warms the water inside the box to produce steam and helps diffuse the aroma through the aroma compartment into the sauna room, creating a more relaxing sauna experience.

Operating Principle

The stainless-steel box functions as a water reservoir with a maximum capacity of 1.9 liters. When installed in the heated area of the sauna heater, heat from the heater is transferred to the water inside the box.

1. Filling the Water Reservoir

- Fill the reservoir with clean water, up to 1.9 liters.
- Do not overfill the reservoir. Leave sufficient space to allow for heating and steam generation.

2. Adding Sauna Aroma

- The unit is equipped with a dedicated aroma compartment located on the top of the box.

Add sauna-specific aroma essence or fragrance to the designated aroma compartment.

3. Heating the Water

- The Aroma Steam Box does not have a separate steam generator. It uses the heat generated by the sauna heater to heat the water.
- The box is positioned within the heated area of the sauna heater, allowing heat to transfer to the water reservoir.

4. Steam and Aroma Diffusion

- Once the water reaches a sufficient temperature, it gradually evaporates and produces steam.

The steam carries the aroma into the sauna room, creating a pleasant aromatherapy sauna experience.

Important Safety & Usage Note ⚠

- The water in the Aroma Steam Box and the aroma oil must be kept separate. Do not pour concentrated essential oil or aroma oil directly into the water reservoir.
- This model is equipped with a dedicated aroma compartment located on the top of the box for adding aroma products.
- The separate aroma compartment is designed to help prevent direct contact between the aroma oil and the heating elements.
- Use only sauna-specific aroma essence or fragrance products that are suitable for high-temperature sauna or steam applications.
- Do not pour aroma oil directly onto the heating elements or other hot surfaces.

